



ENAMELLED CAST IRON GHISA SMALTATA

COOKWARE
PENTOLAME



Suitable for use on all cooking hobs (gas, electric, ceramic, induction) and ovens (gas, oil, coal or wood) except microwave. A perfect harmony of cast iron, enamel and high quality. Designed and constructed to absorb and spread the heat evenly. Cast iron is suitable for all cooking techniques, for soups, roasts, rice, desserts, for braise that require a long cooking and likewise ideal for meats and grilled vegetables as it enhances flavors and aromas like barbecue style. Cast iron also features non-stick. The high temperature of the pan sears the meat surface. All the flavor, water and nutritional values remain sealed in the food. When cooking in casseroles, the steam generated thanks to the special design of the cover condenses falling back into the food not only retaining flavors and aromas but providing the best protection for nutrients and contributing to a healthy diet. Cast iron is a material 100% recyclable and therefore environmentally friendly. Moreover, thanks to its ability to retain heat for a long time it allows a considerable saving of energy. With closed lid on the table, the pot will preserve the temperature for a second serving. Cast iron retains the heat but as well the cold... can be used to keep the food fresh. Stored for a short time in the refrigerator, keeps food cool during hot summer days, ideal for serving pasta or rice salads, etc. Practical and easy to clean. These cast iron pots and pans are dishwasher safe thanks to the special technology applied to their enameling method. Ergonomic knobs and handles made of cast iron and stainless steel, suitable for use on all heat sources and ovens except microwave. Be careful, they heat up during cooking, it is recommended to handle with a dry thick cloth.

Idonee all'uso su tutte le fonti di cottura (gas, elettriche, vetroceramica, induzione) e forni (gas, petrolio, carbone o legna) ad esclusione di microonde. Una perfetta armonia tra ghisa, smalto e alta qualità. Progettate e costruite per assorbire e diffondere il calore in modo uniforme. La ghisa è adatta a tutte le tecniche di cottura, per zuppe, arrostiti, risotti, dolci, per piatti che richiedono una lunga cottura tipo brasati e allo stesso modo ideale per carni e verdure alla griglia in quanto ne esalta sapori ed aromi in stile barbecue. La ghisa ha anche caratteristiche di antiaderenza. La temperatura elevata della padella cauterizza la superficie della carne. Tutto il sapore, l'acqua e i valori nutrizionali rimangono sigillati nel cibo. Nella cottura in casseruole, il vapore generato grazie al particolare design del coperchio si condensa ricadendo e mescolandosi nuovamente nel cibo non solo trattenendo sapori e aromi ma fornendo la miglior protezione alle sostanze nutrienti e contribuendo ad una dieta sana. La ghisa è un materiale riciclabile al 100% e quindi ecologico. Inoltre, grazie alla sua capacità di mantenere il calore per lungo tempo consente un notevole risparmio di energia permettendo di cuocere a fuoco basso. Anche a tavola mantengono in cibi in temperatura. La ghisa mantiene però il caldo come pure il freddo... può essere usata per mantenere il cibo fresco. Riposta per un breve periodo in frigorifero, mantiene il cibo fresco nelle calde giornate estive e ideale per servire insalate di pasta, riso, farro, ecc., ecc. Pratica e facile da pulire. Queste casseruole e padelle in ghisa sono lavabili in lavastoviglie, per merito della speciale tecnologia applicata al metodo di smaltatura. Manicatura e pomoli dal design ergonomico sono in ghisa e inox. Durante la cottura si raccomanda di maneggiare con un panno consistente e asciutto per evitare di scottarsi.



Saucepot round with lid
Casseruola tonda con coperchio
Fleischtopf, rund mit Deckel
Brasière avec couvercle
Cacerola redonda con tapa

art.	Ø cm.	lt.	col.
44201R10	10	0,35	●
44201V10	10	0,35	●
44201B10	10	0,35	●
44201O10	10	0,35	●
44201N10	10	0,35	●

Portion: – Porzioni: 1



Saucepot round with lid
Casseruola tonda con coperchio
Fleischtopf, rund mit Deckel
Brasière avec couvercle
Cacerola redonda con tapa

art.	Ø cm.	lt.	col.
44201R12	12	0,55	●
44201V12	12	0,55	●
44201B12	12	0,55	●
44201O12	12	0,55	●
44201N12	12	0,55	●

Portion: – Porzioni: 1



Oval saucepan with lid
Casseruola ovale con coperchio
Ovaler Bratentopf mit Deckel
Casserole ovale avec couvercle
Cacerola oval con tapa

art.	cm.	col.
44202R12	12x9x6	●
44202V12	12x9x6	●
44202B12	12x9x6	●
44202O12	12x9x6	●
44202N12	12x9x6	●

Portion: – Porzioni: 1



W

Saucepot stand
Supporto casseruolina
Fleischtopf-Träger
Support pour brasière
Soporte para cacerola

art.	Ø cm.
44201-01	10



W

Saucepot stand
Supporto casseruolina
Fleischtopf-Träger
Support pour brasière
Soporte para cacerola

art.	Ø cm.
44201-03	10



W

Saucepot platter
Sottopentola
Fleischtopfbrett
Planche à casserole
Tabla para cacerola

art.	Ø cm.
44201-10	10-12



W

Saucepot platter
Sottopentola
Fleischtopfbrett
Planche à casserole
Tabla para cacerola

art.	cm.
44202-10	12x9



Soufflé pot with wooden platter
Coppa soufflé con piatto legno
Ramekin mit Holzbrett
Ramequin avec planche bois
Fuente soufflé con tabla madera

art.	Ø cm.	lt.
44240S08	8	0,17

Portion: – Porzioni: 1



Saucepot with lid
Casseruola alta con coperchio
Fleischtopf mit Deckel
Brasière avec couvercle
Cacerola alta con tapa

art.	Ø cm.	lt.	Por.
44201R16	16	1,0	1-2
44201R20	20	2,6	2-3
44201R24	24	4,5	4-5
44201R28	28	6,7	6-8
44201R32	32	10,0	12-16



Saucepot with lid
Casseruola alta con coperchio
Fleischtopf mit Deckel
Brasière avec couvercle
Cacerola alta con tapa

art.	Ø cm.	lt.	Por.
44201N16	16	1,0	1-2
44201N20	20	2,6	2-3
44201N24	24	4,5	4-5
44201N28	28	6,7	6-8
44201N32	32	10,0	12-16



Saucepot with glass lid
Casseruola alta coperchio vetro
Fleischtopf mit Glasdeckel
Brasière avec couvercle verre
Cacerola alta con tapa vidrio

art.	Ø cm.	lt.	Por.
44203R20	20	2,6	2-3
44203R24	24	4,5	4-5
44203R28	28	6,7	6-8



Oval saucepan with lid
Casseruola ovale con coperchio
Ovaler Bratentopf mit Deckel
Casserole ovale avec couvercle
Cacerola oval con tapa

art.	Ø cm.	lt.	Por.
44202R25	25	3,3	4
44202R27	27	4,0	4-6
44202R29	29	4,8	6



Oval saucepan with lid

Casseruola ovale con coperchio
Ovaler Bratentopf mit Deckel
Casserole ovale avec couvercle
Cacerola oval con tapa

art.	Ø cm.	lt.	Por.
44202N25	25	3,3	4
44202N27	27	4,0	4-6
44202N29	29	4,8	6



Casserole pot with glass lid

Casseruola bassa coperchio vetro
Bratentopf mit Glasdeckel
Sautoir avec couvercle verre
Cacerola baja con tapa vidrio

art.	Ø cm.	lt.	Por.
44204R24	24	2,4	4
44204R28	28	3,4	4-6



Saucepan with glass lid

Casseruola alta con coperchio vetro
Stielkasserolle, hoch mit Glasdeckel
Casserole haute avec couvercle verre
Cazo recto alto con tapa vidrio

art.	Ø cm.	lt.	Por.
44239R16	16	1,0	1-2



Frypan

Padella
Bratpfanne
Poêle

Sartén

art.	Ø cm.	lt.	Por.
44205-16	16	0,42	1
44205-20	20	0,80	1-2



Frypan wooden handle

Padella manico legno
Bratpfanne mit Holz-Griff
Poêle manche bois

Sartén mango maderera

art.	Ø cm.	lt.	Por.
44205-24	24	1,5	4
44205-28	28	2,5	4-6



Wok pan

Wok
Wok-Pfanne
Poêle chinoise

Wok

art.	Ø cm.	lt.	Por.
44247-38	38	5,3	4





W

Platter with magnetic feature

Sottopentola magnetico
Untersetzer, magnetisch
Sous-plat magnétique
Posavasos magnético

art.	Ø cm.
44207-16	16
44207-20	20
44207-24	24
44207-28	28



Grill pan

Padella grill
Grill-Pfanne
Poêle grill
Sartén grill

art.	cm.	lt.	Por.
44209R26	26x26	2,2	4
44209R32	26x32	2,6	6



Grill pan

Padella grill
Grill-Pfanne
Poêle grill
Sartén grill

art.	cm.	lt.	Por.
44210-26	26x26	2,20	4
44210-32	26x32	2,75	6



Silicone sleeves

Coprimaniglie silicone
Silikon-Griffhüllen
Revêtement en silicone pour poignées
Cubre asas de silicona

art.	col.
44208G00	●
44208R00	●



Grill pan with wooden service stand

Padella grill con tagliere a servire legno
Grill-Pfanne mit Service-Holzbrett
Poêle grill avec support à servir bois
Sartén grill con tabla madera

art.	cm.	lt.	Por.
44210S26	26x26	2,20	4
44210S32	26x32	2,75	6



Grill pan

Padella grill
Grill-Pfanne
Poêle grill
Sartén grill

art.	cm.	lt.	Por.
44210-42	31x42	4,5	8



Grill pan with wooden service stand

Padella grill con tagliere a servire legno
Grill-Pfanne mit Service-Holzbrett
Poêle grill avec support à servir bois
Sartén grill con tabla madera

art.	cm.	lt.	Por.
44210S42	31x42	4,5	8



Bake roasting dish

Tegame rettangolare
Pfanne, rechteckig
Plat rectangulaire
Rustidera

art.	cm.	Por.
44218R30	22x30	6-8
44218R40	26x40	8-12



Terrine pot

Terrina
Pasteten-Pfanne
Terrine rectangle
Fuente rectangular

art.	cm.	Por.
44219R26	8,5x26,5x6	2-4



Grill pan and wooden service stand

Padella grill con tagliere a servire legno
Grill-Pfanne mit Service-Holzbrett
Poêle grill avec plaque à servir bois
Sartén grill con tabla madera

art.	cm.	Por.
44216S16	16x16	1

Cups not included. – Ciotoline non incluse.





Grill pan with wooden platter
Padella grill con tagliere legno
Grill-Pfanne mit Holzbrett
Poêle grill avec plaque bois
Sartén grill con tabla madera

art.	cm.	Por.
44215S16	16x16	1



Griddle plate, dual side, reversible
Griglia reversibile
Grill-Platte, zweiseitig, reversible
Gril rectangle, reversible
Parrilla reversible

art.	cm.	Por.
44217-45	26x47	6-8



Grill pan
Bistecchiera
Grill-Pfanne
Poêle grill
Sartén grill

art.	Ø cm.	lt.	Por.
44212-30	30	2,35	4-6



Grill pan
Bistecchiera
Grill-Pfanne
Poêle grill
Sartén grill

art.	cm.	Por.
44213-24	24x24	1-2
44213-36	21x36	2-4



Grill pan
Bistecchiera
Grill-Pfanne
Poêle grill
Sartén grill

art.	Ø cm.	Por.
44214-25	25	2-3



Fish plate with wooden platter
Piatto pesce con tagliere legno
Fischplatte mit Holzbrett
Plat à poisson avec planche bois
Fuente pescado con tabla madera

art.	cm.	Por.
44220S24	15x24	1-2



Fish plate with wooden platter
Piatto pesce con tagliere legno
Fischplatte mit Holzbrett
Plat à poisson avec planche bois
Fuente pescado con tabla madera

art.	cm.	Por.
44221S30	15,5x29,5	1-2



Pizza pan
Piatto pizza
Pizza-Platte
Plat à pizza
Fuente para pizza

art.	Ø cm.	Por.
44222-20	20	1
44222-28	28	1



Pizza pan with wooden platter
Piatto pizza con tagliere legno
Pizza-Platte mit Holzbrett
Plat à pizza avec planche bois
Fuente para pizza con tabla madera

art.	Ø cm.	Por.
44222S20	20	1
44222S28	28	1



Griddle plate, dual side, reversible
Griglia reversibile
Grill-Platte, zweiseitig, reversible
Grill rectangle, reversible
Parrilla reversible

art.	cm.	Por.
44224-22	22x15	1-2



Grill plate and wooden platter

Griglia reversibile con tagliere legno
Grill-Platte mit Service-Holzbrett
Grill avec plaque à servir bois
Parrilla con tabla madera


art.	cm.	Por.
44224S22	22x15	1-2



Table barbecue

Barbecue da tavola
Tischgrillplatte
Barbecue de table
Parrilla de mesa

art.	cm.	Por.
44225-22	22x15	1-2



Griddle with wooden platter

Griglia con tagliere legno
Grill-Platte mit Holzbrett
Grill rectangle avec planche bois
Parrilla con tabla madera

art.	cm.	Por.
44226S30	22x30	2-3



Table barbecue

Barbecue da tavola
Tischgrillplatte
Barbecue de table
Parrilla de mesa

art.	cm.	Por.
44227-30	22x30	2-3



Fajita plate with wooden platter

Piatto fajita con tagliere legno
Fajitaplatte mit Holzbrett
Plat à fajitas avec planche bois
Fuente fajitas con tabla madera

art.	cm.	Por.
44228S23	17x23	1



Fajita plate with wooden platter

Piatto fajita con tagliere legno
Fajitaplatte mit Holzbrett
Plat à fajitas avec planche bois
Fuente fajitas con tabla madera

art.	cm.	Por.
44229S20	10x20	1



Oval plate with wooden platter

Piatto ovale con tagliere legno
Ovalplatte mit Holzbrett
Plat oval avec planche bois
Fuente ovale con tabla madera

art.	cm.	Por.
44230S10	15x10x2,5	1
44230S14	21x14x2,5	1-2



Oval plate with wooden platter

Piatto ovale con tagliere legno
Ovalplatte mit Holzbrett
Plat oval avec planche bois
Fuente ovale con tabla madera

art.	cm.	Por.
44231-14	21x14x2,5	1-2

Cups not included. – Ciotoline non incluse.



Round plate with wooden platter

Piatto tondo con tagliere legno
Platte mit Holzbrett, rund
Plat rond avec planche bois
Fuente redonda con tabla madera

art.	Ø cm.	Por.
44232S12	12	1
44232S16	16	1-2
44232S20	20	2-3



Round plate with wooden platter

Piatto tondo con tagliere legno
Platte mit Holzbrett, rund
Plat rond avec planche bois
Fuente redonda con tabla madera

art.	Ø cm.	lt.	Por.
44233-16	16	0,46	1-2
44233-20	20	0,74	3-4

Cups not included. – Ciotoline non incluse.



Round pan

Padella tonda
Pfanne, rund
Poêle ronde
Sartén grill redonda

art.	Ø cm.	Por.
44234-12	12	1
44234-16	16	1-2



Pan and wooden platter

Padella con tagliere legno

Pfanne mit Holzbrett

Poêle avec plaque bois

Sartén grill con tabla madera

art.	Ø cm.	lt.	Por.
44234S12	12	0,24	1
44234S16	16	0,45	1-2



Pan and wooden platter

Padella con tagliere legno

Pfanne mit Holzbrett

Poêle avec plaque bois

Sartén grill con tabla madera

art.	Ø cm.	lt.	Por.
44235-16	16	0,45	1-2

Cups not included. – Ciotoline non incluse.



Rectangular pan with wooden service stand

Tegame con tagliere a servire legno

Pfanne mit Service-Holzbrett

Poêle avec support à servir bois

Sartén con tabla madera

art.	cm.	Por.
44237S15	12x15	1-2



Rectangular pan with wooden service stand

Tegame con tagliere a servire legno

Pfanne mit Service-Holzbrett

Poêle avec support à servir bois

Sartén con tabla madera

art.	cm.	Por.
44238-15	12x15	1-2

Cups not included. – Ciotoline non incluse.



W

Tortillas cup

Ciotola tortillas

Tortillas-Schale

Coupe-tortillas

Copa tortillas

art.	Ø cm.
44241-19	19



Soufflé pot, enameled cast iron

Coppa soufflè, ghisa smaltata

Ramekin, emailliertes Gusseisen

Ramequin, fonte émaillée

Fuente soufflè, hierro fundido esmaltado

art.	Ø cm.	lt.	Por.
44240-08	8	0,15	1



PR

Sauce bowl

Coppa salsa

Saucentasse

Bol à sauce

Copa para salsa

art.	Ø cm.	h.
44242-00	6	2,7



MF

Sauce bowl

Coppa salsa

Saucentasse

Bol à sauce

Copa para salsa

art.	Ø cm.	h.
44243-00	7,1	3,5



Oval plate with wooden platter

Piatto con tagliere legno

Ovalplatte mit Holzbrett

Plat oval avec planche bois

Fuente oval con tabla madera

art.	cm.	lt.	Por.
44223S19	12,5x19	0,23	1



Griddle plate, reversible with wooden platter

Griglia reversibile con tagliere legno

Grill-Platte, reversibile mit Holzbrett

Gril reversible avec planche bois

Plancha grill reversible con tabla madera

art.	Ø cm.	Por.
44236S28	28	4
44236S34	34	6



Service dish with wooden stand

Piatto servire con tagliere legno

Servier-Platte mit Holzbrett

Plat à servir avec support en bois

Plato para servir con tabla madera

art.	cm.	Por.
44245S32	32x20	1



Service dish with porcelain surface

Tagliere con superficie porcellanata

Servierplatte mit Porzellan-Oberfläche

Plat à servir avec surface en porcelaine

Tabla con superficie porcelana

art.	cm.	Por.
44255-10	39,5x25x2,5	1

Incl. casserole Ø 10 cm with lid. Sauce cups not included. – Incl. casseruola c/cop. ø 10 cm. Coppette salsa escluse.



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	Por.
44255-12	39,5x25x2,5	1

Incl. oval casserole 12 cm with lid. Sauce cups not included. – Incl. casseruola ovale c/cop. 12 cm. Coppette salsa escluse.



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	Por.
44255-14	39,5x25x2,5	1
44255-16	39,5x25x2,5	1-2

Incl. skillet ø 12/16 cm. Sauce cups not included.
Incl. padella ø 12/16 cm. Coppette salsa escluse.



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	Por.
44255-15	39,5x25x2,5	1-2

Incl. dish 12x15 cm. Sauce cups not included.
Incl. tegamino 12x15 cm. Coppette salsa escluse.



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	Por.
44255-21	39,5x25x2,5	1-2

Incl. dish 21x14 cm. Sauce cups not included.
Incl. tegamino 21x14 cm. Coppette salsa escluse.



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	Por.
44255-22	39,5x25x2,5	1-2

Incl. pan ø16 cm. Sauce cups not included.
Incl. tegamino ø 16 cm. Coppette salsa escluse.



Plate pig with wooden platter
Piatto maiale con tagliere legno
Platte Schwein mit Holzbrett
Plat porc avec planche bois
Plato cerdo con tabla madera

art.	cm.	lt.	Por.
44220S32	32,5x17,5	0,38	1-2



Plate fish with wooden platter
Piatto pesce con tagliere legno
Platte Fisch mit Holzbrett
Plat poisson avec planche bois
Plato pescado con tabla madera

art.	cm.	lt.	Por.
44220S38	24,5x16,5	0,12	1



Pan with wooden platter
Tegame con tagliere legno
Pfanne mit Holzbrett
Poêle avec planche bois
Paellera con tabla madera

art.	Ø cm.	cm.	lt.	Por.
44247S16	16	23,5x18,5	0,44	1-2



Service dish with porcelain surface
Tagliere con superficie porcellanata
Servierplatte mit Porzellan-Oberfläche
Plat à servir avec surface en porcelaine
Tabla con superficie porcelana

art.	cm.	lt.	Por.
44255-08	39,5x28x4,3	0,17	1

Incl. dish 16x25 cm. Sauce cups not included.
Incl. piatto 16x25cm. Coppette salsa escluse.



Service dish with wooden stand
Piatto servire con tagliere legno
Servierplatte mit Holzbrett
Plat à servir avec support en bois
Plato para servir con tabla madera

art.	cm.	Por.
44244S30	30x15	1-2
44244S36	36x24	4-6



Hot pot with wooden stand
Casseruola con tagliere legno
Schüssel mit Holzbrett
Bol avec support en bois
Bol con tabla madera

art.	Ø cm.	h.	lt.	Por.
44246S11	11	4	0,21	1
44246S14	14	4	0,32	1
44246S17	17	4	0,59	1